

# PARTS LIST

for



# Whirlpool

## ELECTRIC DRYER

**MODEL**  
**LE7000XKW-0**

▲W—White, N—Almond,  
G—Golden Harvest



FOR CUSTOMER SATISFACTION ALWAYS USE  
FACTORY SPECIFICATION PARTS



**Whirlpool CORPORATION**

Benton Harbor, Michigan.


FOR SERVICE INFORMATION  
SEE SERVICE (BROWN) FILMCARD(S)

2-A-2 & 33.1-F-6

147-G-9

# TOP AND CONSOLE PARTS

For Model LE7000XKW-0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

For Model LE7000XKW-0

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	346368	Panel, Rear	11		Cover, Lint	39		Switch,
2	343641	Screw, 10-16 x 1/2			Screen			Push-To-Start
3	355326	Screw,		688150	White		685067	Alternate
		13-16 x 5/8 (4)		689310	Almond		348771	Alternate
4		Cap, End L.H.		689313	Golden Harvest	48	690200	Timer Knob
	375305	White	12	339229	Hinge, R.H.			Assembly
	375313	Almond		339230	Hinge, L.H.	50	357645	Rack, Literature
	375318	Golden Harvest	13	688983	Screw, 8-18 x 5/8	53	359708	Bracket, Control
		Cap, End R.H.	16		Top	54	691676	Panel, Control
	375309	White		688479	White	62	688805	Clip
	375315	Almond		689449	Almond	63	90015	Clip
	377283	Golden Harvest		689452	Golden Harvest	64	689857	Button,
5	†691086	Harness, Wiring	18	690304	Control Knob			Push-To-Start
6	686726	Resistor & Shield			Assembly	67	689559	Nut, Push-In (4)
		Assembly	21	690344	Timer & Resistor	72	690853	Wire, Ground
7	358225	Screw, 8-18 (2)			Assembly, 60 Hz.	76	686864	Buzzer, Mini
9	358472	Stop, Push-In (2)	29	339554	Screw, Tapping	79	688710	Thermostat,
10	339392	Screen, Lint	30	358473	Nut, Push-In (2)			Adjustable

## LITERATURE AND OPTIONAL PARTS


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b>LITERATURE PARTS</b>			<b>OPTIONAL PARTS NOT INCLUDED</b>			<b>PAINTS</b>		
	688643	Instructions, Installation	Following Parts Are Used Outside The U.S. For 2-Wire 240-Volt Installations					Paint, Touch-Up
	688898	Guide, Dryer						(1/2 Oz.)
	691262	Use & Care Guide		299032	Transformer Assembly		72017	White
	691513	List, Service Parts		340704	Supplement, Installation Instructions		72107	Almond
							72110	Golden Harvest
								Spray Paint
								(13 Oz.)
				230083	Instructions, Wiring		350930	White
				339896	Instructions, Harness Rework		350956	Almond
							261890	Golden Harvest
							350938	Primer, Gray
							350941	Leveler (Thinner)
								Paint, Touch-Up
								(1 Qt.)
				†Use	10875 Wire, Splicing 120 Volt		*799344	White (Uncut)
					299885 Wire, Splicing 240 Volt		*978883	Almond (Uncut)
							*261891	Golden Harvest (Uncut)
							799351	Thinner (1 Gal.)

\*Special Thinner 799351 Required.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Model LE7000XKW-0



Illus. No.	Part No.	DESCRIPTION
1	299693	Lint Chute Assembly
2	687128	Screw, 10-16 x 1/2
4	347139	seal, Lint Chute
5	90767	Screw, 8A x 3/8
6	689790	Dry Rack Assembly
7	688841	Thermal Fuse (Alternate)
	690198	Thermal Fuse (Alternate)
10	343939	Wheel, Blower
11	688880	Housing, Blower
12	337272	Clip
13	343641	Screw, 10-16 x 1/2


Illus. No.	Part No.	DESCRIPTION
14	685457	Box, Heater
15	341195	Thermostat, 250°F (121.1°C) (Alternate)
17	690241	Element, Heater
	690983	Alternate (Use 279139 Jumper Wire For Heater Element Harness Terminal Replacement)
41	690997	Ring, Tri
42	347364	Shaft, L.H.

Illus. No.	Part No.	DESCRIPTION
43	339489	Shaft, R.H.
44	349241	Roller, Support
45	98460	Nut, Push-In (2)
46	348197	Washer, Support
47	120377	Nut, 3/8-16
48	685769	Bulkhead
62	337651	Ring, Bearing
63	690372	Screw, 11-16 x 7/8
66	337449	Seal, Rear Drum
67	338010	Drum Assembly
69	348945	Bracket, Support
70	90296	Clip
71	342847	Baffle, Drum (1)
73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Model LE7000XKW-0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Model LE7000XKW-0

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	343641	Screw, 10-16 x 1/2	26	337189	Clip, Hinge (2)	51	238088	Hinge, Top (2)
2	687128	Screw, 10-16 x 1/2	27	689791	Screw	53	688166	Idler & Pulley Assembly
3	690989	Screw, 10-32 x 1/2	28	687905	Hinge, R.H.	56	341241	Belt, Drive
4	238614	Bumper		687906	Hinge, L.H.	57	348780	Base, Motor
5	690893	Cover, Block	31	98997	Clip, Harness	58	172455	Bolt, 5/16-18 x 3/4
6	342043	Screw, 10-32 x 1/2	33	690082	Strike, Door	59	685011	Pulley, 60 Hz. (Includes Illus. 60)
7	346368	Panel, Rear	35		Door, Rear	60	690046	Set screw
9	295998	Clip, Door Switch		346370	White	61	337351	Switch (Use W/690870 Motor)
10	347207	Switch, Door		689258	Almond		349588	Switch (Use W/689788 Motor)
11	98129	Screw, 6-20 x 7/8		689261	Golden Harvest	62	689788	Motor Assembly 60 Hz. (Alternate)
12	690236	Wire, Ground (Motor)	36		Door, Front		690870	Motor Assembly 60 Hz. (Alternate)
13	98518	Screw, 10-12 x 1/2		348728	White	63	343481	Clamp, Motor (Alternate)
14	237979	Spring, Door (2)		689330	Almond		685441	Clamp, Motor (Alternate)
15	690625	Clip, Toe Panel (2)	37	689333	Golden Harvest	67	685762	Seal, Door
16	688222	Foot, Dryer (Plastic) (4)		690265	White	68	688412	Clip, Retainer Terminal
18		Cabinet		690266	Almond	70	348912	Tinned Brass
	690847	White	38	690269	Golden Harvest	71	691207	Door, Filler Lg.
	690848	Almond		349464	Seal & Bearing Assembly	72	691525	Alternate
	690851	Golden Harvest	40	98518	Screw		691206	Alternate
19	98234	Clip, Ground (2)	41	690261	Block, Terminal			
20	688904	Lock, Front Top (2)	42	279393	Terminal Block Kit (For Terminal Block)			
21		Upper Front Panel Assembly	46	341776	Clip, Toe Panel Lock			
	337969	White	48	297092	Clip, Hinge (2)			
	689334	Almond	49		Panel, Toe			
	689337	Golden Harvest		337833	White			
23	685203	Clip, Felt Pad (2)		689246	Almond			
24	690081	Catch, Door		689249	Golden Harvest			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST